

JUMPER	PIN DEFINITION		
J2	Display Type Select Open Mono/EGA/VGA (default) Short Color		
J3	External, Internal Battery Select 1-2 External battery 2-3 Internal battery (default)		
J4	Local IDE Select 1-2 Enable 2-3 Disable		
JP4	Local IDE 1-2 Default 2-3 For VESA Local VGA Card installed at VESA slot 0 only		
J5, J6	HDD Speed Select (PDC 20230 Only) IDE Type J5 J6 Speed 0 2-3 2-3 Speed 1 1-2 2-3 (default) Speed 2 1-2 1-2		
J7	Password Clear (Award/AMI BIOS Select) Short Clear password Open (default)		
J9	HDD_BALE Short Enable Open Disable (default)		
J10	HDD_IOCHRDY Short Enable Open Disable (default)		
J18	Short Adaptec ISA Master 1542B/C SCSI card only (Transfer rate \geq 5.7MB/s) Open Default (Transfer rate < 5.7MB/s)		
JC6	80486SX/P23S/P4S/CX486S PQFP Select Short Disable Open Enable		
JT1	P24T Write-back/Write-through Select 1-2 Write-back 2-3 Write-through		
JX1	CPU Clock Select 1-2 1 X (default) 2-3 2 X		
JX3, JX4	JX3 1-2 1-2	JX4 2-3 1-2	Reserved External KBC (default)

Table 2-2. Jumper Definitions