

Table of Contents

Chapter 1 Overview

Package Checklist.....	1
The VL-603 Mainboard.....	2
Main Features.....	3
Advanced Features	4
DMI (Desktop Management Interface)	5
Intel LANDesk® Client Manager (optional).....	5

Chapter 2 Installation Procedures

1). Set System Jumpers.....	8
Components That Concern Installation	9
Clear Password: CPW.....	11
CMOS Clear: CMOS_CLR.....	11
Flash ROM Type Select: EP1, EP2.....	12
2). Install System RAM Modules	12
SDRAM	12
RAM Module Configuration.....	13
Install DIMMs.....	13
Remove DIMMs	14
3). Install the Central Processing Unit (CPU)	15
Retention Mechanism Kit (for Pentium® II or Deschutes CPU).....	15
CPU Module Installation	16
Retention Mechanism (for Covington CPU).....	21
CPU to Bus Frequency Ratio: FREQ.....	21
Intel Pentium II CPUs.....	22
4). Install Expansion Cards.....	22
5). Connector Cables and Power Supply	23
Serial Port Connectors (Two 9-pin Male): COM1, COM2	23
PS/2 Keyboard and Mouse Connector: PS1	24
Printer Connector: LPT1.....	24
Universal Serial Bus Connectors: USB.....	25
Audio Port Connectors: LINE-OUT, LINE-IN, MIC	25
Joystick/MIDI Connector: GAME	26
CPU Fan Connector (3-pin Male): CPU_FAN	26
System Case Fan Connector (3-pin Male): CHAS_FAN	27
Floppy Diskette Drive Connector (34-pin block): FDD.....	28
IDE HDD Device Connectors: PRIMARY, SECONDARY	29

Front Panel Block Connector: F_PNL	29
Infrared Connector: IR.....	31
ATX Power Connector: ATX_PWR.....	32
Remote Wake-Up Connector (3-pin Male): RWU.....	32
CD-ROM Drive Audio-out Connector (4-pin block): CD_IN	33
PCI Add-on Audio Card Connector (6-pin Male): SB_LINK	33
Power Connection Procedures.....	34
Powering Off the Computer.....	34

Chapter 3 Setting BIOS Feature

Main CMOS Setup	36
Load Defaults	36
Standard CMOS Setup	36
Auto Detection of Hard Disks on Bootup.....	38
Software Turbo Speed	39
BIOS Features Setup	39
Chipset Features Setup	42
Power Management Setup	45
PNP and PCI Configuration Setup.....	49
Load BIOS Defaults	50
Load Setup Defaults	51
Integrated Peripherals.....	51
Supervisor Password and User Password	54
IDE HDD Auto Detection	55
Save and Exit Setup.....	56
Exit Without Saving	56

Chapter 4 Software Utilities

Starting Installation	57
LANDesk® Client Manager (optional)	57
Three Options of the LDCM Setup.....	57
Desktop Management Interface (DMI).....	59
Starting DMI	59
IDE Bus Master Driver.....	60
Patch for Chipset	61
BIOS Flash Software.....	61
Download and Upgrade BIOS File	61
Anti-Virus Tool	63

Table Of Contents

Hardware Requirements.....	63
Technical Notes	63
Onboard Audio Chip Driver Installation	63
OPL3-SA2 Installation for Windows 3.1 and DOS	63
YAMAHA STATION	64
Installation	64
SETUPSA	67
OPL3-SAx Configuration	68
SoftSynthesizer Configuration	68
MIC Volume Control.....	69
ZV Port	69
IDE CD-ROM Interface.....	69
OPL3-SA3 Installation for Windows 95.....	69
Sound System and Game Port Installation	69
Confirmation of Installation.....	70
OPL3-SAx Power Management.....	70
Features	71
How To Use	71
OPL3-SAx Configuration	72
SoftSynthesizer Configuration	72
MIC Volume Control.....	73
Tone Configuration	73
3D Enhancement Control on Volume Control.....	73
Installation of an Application and the Configuration Utility....	73
Installation of the Application.....	74
Installation of the Configuration Utility.....	74
Using IDE CD-ROM Interface in the DOS-Mode	74
OPL3-SA3 Installation for Windows 95 (OSR2).....	74
Sound System and Game Port Installation	75
Confirmation of Installation.....	75
OPL3-SAx Configuration	76
SoftSynthesizer Configuration	76
MIC Volume Control.....	76
Tone Configuration	76
3D Enhancement Control on Volume Control.....	76
Installation of an Application and the Configuration Utility....	76
Installation of the Application.....	77
Installation of the Configuration Utility	77
Using IDE CD-ROM Interface in the DOS-Mode	77

