







Password Clear: JCP

| Password Clear | JCP |
|-------------------|---|
| Enable |  |
| Disable (Default) |  |











Display Type Select: J2


| Display Type | J2 |
|------------------------|---|
| CGA |  |
| Mono/VGA/EGA (Default) |  |









SRAM Type Select: JPW1, JPW2, JPW3, JPW4

| SRAM Voltage | JPW1 | JPW2 |
|-----------------|---|---|
| Mixed (Default) |  |  |
| 3.3V |  |  |

| SRAM Voltage | JPW3 | JPW4 |
|-----------------|---|---|
| Mixed (Default) |  |  |
| 3.3V |  |  |



Flash EPROM Type: J3, J4

| Programmable Flash EPROM Type | J3 | J4 |
|-------------------------------|---|---|
| Intel 28F010 |  |  |
| Intel 28F001BX-T |  |  |
| SST 29EE010 (Default) |  |  |

