

Table of Contents

1. Introduction

Main Features	1-1
Mainboard Description	1-1
Specification	1-2
Mainboard Layout	1-4

2. Installation

Check List	2-1
Dimensions	2-2
Install Main Memory	2-2
Cache Memory	2-4
Install CPU	2-4
CPU frequency and Bus frequency	2-5
Intel Pentium® processor or Intel Pentium ® processor with MMX™ technology	2-5
Cyrix or IBM 6x86 CPU	2-6
AMD K5 CPU	2-7
Set the Jumpers for CPU Voltage	2-8
CPU Fan	2-9
Install Fan Power On-board	2-10
Install Cables	2-10
IDE Connector	2-10
Floppy Disk Connector	2-11
IrDA	2-11
USB Header	2-12
20-pin Front Panel Switch Connector	2-12
AT & ATX Power Supply Connector	2-15
PS/2 Mouse & Keyboard Connector	2-15
Serial Port COM1 and COM2	2-16
Parallel Port Printer Connector	2-16
Install Add-on Card	2-17
Other Jumpers	2-17
Clear CMOS (JP4) and Clear Password (JP2)	2-17
Host Clock Setting	2-18

3. Built-in BIOS Setup Program

SETUP Program	3-1
Standard CMOS Setup	3-3
BIOS Features Setup	3-4
Chipset Features Setup	3-6
Power Management Setup	3-10
PNP/PCI Configuration Setup	3-12
Load BIOS Defaults	3-13
Load Optimum Setting	3-13
Integrated Peripherals	3-14
Supervisor Password	3-16
User Password	3-16
IDE HDD Auto Detection	3-16
Quitting SETUP	3-18

About this Manual

This manual is designed to offer detailed information about the P5TX-A mainboard. The content includes the main features of the mainboard, the installation , and the BIOS settings. There are three chapters to offer clear and detailed information of P5TX-A.

- Chapter 1 Introduction**
Describes the main features and major components.
- Chapter 2 Installation**
Describes the installation of hardware including jumpers , cables and connectors.
- Chapter 3 BIOS Setup**
Describes the setup of BIOS. Briefly explain each item and show the selection of option.

Warning Marks

In this manual , **warning marks** are used to stress important parts or notices of text that require users' attention. There are two kinds of warning marks in this manual:




Stress the important information or instructions that must pay more attentions to and should be noted.



Avoid the possible system error or damages , and offer detailed information.

Graphic Descriptions of Jumper Settings



means Pin 1 & Pin 2 are set as short



means Pin 1 & Pin 2 are set as open